

Cut around outside edges only. Do not cut out the center.

Make 4 slits in inner ring for Payload Attachment ring.
Use a good straight edge like a metal ruler to make crisp folds.
Fold six side panels with gold colored equipment boxes on the outside to form a hexagonal (6-sided) base for the spacecraft Glue the "Fold Tab In" to the inside of the adjacent side panel.



Payload Attachment Fitting. Form into a circular band. Slip tabs into slits in the middle of the base ring. Then fold tabs over and glue on inside and glue end tab.





